

Installation Guide

for EcoGard Lite Rooflights




www.lonsdalemetal.co.uk



Step 1

Check the overall upstand dimensions including the roof finish are correct and ensure it is square. This can be done by checking the diagonal dimensions are the same. Make sure the upstand height is a minimum of 150mm above the roof finish to prevent water ingress by bouncing rain. Check the width of the curb is 50mm or if wider, that the rooflight cill is adapted to suit.




Step 2

Ensure the top surface of the upstand is clean, dry and free from dust and debris. It should be as even a surface as possible without undulation. Apply the seating tape supplied making sure any joints are butted up tight.




Step 3

Apply a continuous mastic bead (not supplied) to the outside edge of the tape for maximum air-tightness.




Step 4

If curb thickness is more than 50mm, check if plasterboard trim (a) is removed before fitting the rooflight.



Step 5

Make sure the inside surface of the glass is clean before carefully lowering the rooflight into position. Check from inside that it is properly centred and has an even gap around all inside edges for plasterboard and finishing.



Step 6

Fix the rooflight through the factory drilled holes using the screws provided. Be careful not to over tighten the screws as this may cause damage to frame corners



Step 8

Installation of the EcoGard Lite rooflight is complete. Now is the time to clean off any dirt and debris using a mild detergent solution. Finally, polish with glass cleaner and a soft cloth.



We're here to help!

For further advice call:

020 8801 4221 Mon – Thurs between 08.30am and 5pm
and up until 4pm on Fridays

Contact us



020 8801 4221



www.lonsdalemetal.co.uk



020 8801 1287



info@lonsdalemetal.co.uk

Unit 40, Millmead Industrial Centre,
Mill Mead Road, London N17 9QU



@lonsdalemetal

LMC **Lonsdale**
PATENT GLAZING & ROOFLIGHTS